





## NUmedia Parental Control - Quick Guide

Your NUmedia 2.0 provides you with full parental control to restrict any unwanted viewing options.


Simply login to your NUmedia player and click on "SETTINGS" icon from top right of your screen.




Scroll down in the settings menu to "PARENTAL CONTROL" and click on it.



A Parental Password window will appear. Simply enter your desired restricted password and click on Submit. Please remember this password for future access in future.






The Categories menu will appear and you can choose to restrict any number of categories by clicking on the lock icon. The locked categories will now be removed from your main menu Categories.



## Un Locking Your NUmedia Parental Control

To "Un Lock" parental control, simply repeat the process by going to Settings, Parental and enter your Parental Password. Then click again on the locked category to unlock.



Please feel free to contact us anytime with any issues at:  
NuMedia Global Inc  
Support Team (Text SMS: (808) 333-3706  
Email: [support@1numedia.com](mailto:support@1numedia.com)  
Live Chat: [www.1numedia.com/support](http://www.1numedia.com/support)